# **UPC CementSeal SA24 Matte**



## **Product Description**

UPC CementSeal SA24 Matte is a single-component, premium solvent-based matte finish acrylic sealer. Its chemistry provides a matte sealed surface that bonds to concrete and cementitious toppings. Its design features enhance color, rejuvenate and protect surfaces.

#### **ADVANTAGES:**

- VOC Compliant
- · Easy Installation
- Non-Yellowing
- · Matte Finish
- Interior & Exterior Use
  Can be Rolled or Sprayed
- Color Enhancement
- Non-slip if Oxide is Added
- Fast Drying
- Resists Water and Stains

# **Applications**

The uniqueness and universality of its chemistry allows UPC CementSeal SA24 Matte to be used in many applications, including the following:

- New or Old Concrete
  Exterior Hardscapes
- Cementitious Toppings Exposed Aggregate
- **Acid Stained Floors**
- · Interlocking Panels
- Stamped Surfaces
- · Natural Stone
- Porous Brick
- · Masonry Surfaces

### Colors

UPC CementSeal SA24 Matte is available as a Clear base. Pigment packs can be added as well. Contact UPC Sales Rep for info.

# **Packaging**

UPC CementSeal SA24 Matte is available in one size:

5 Gallon Pail

# **Physical Characteristics**

PROPERTY	VALUE
Туре	Thermal Plastic
Solids Contents	24% by weight
60% Gloss(2-4 mil dry film)	88
Flash Point	> 20°F (TCC)
Viscosity	> 1455 cps
Maximum V.O.C.	> 99 grams per liter

### **Product Data**

Coverage:	200-300 SF/gal Textured surface
	300-400 SF/gal Smooth surface
Application temperature:	Approx. 55-85°F
Thinning:	Not Required
Cure time:	4-6 Hours for Foot Traffic
	48 Hours for Vehicle Traffic
	5 Days for Full Properties
Critical recoat time:	Approx. 1-2 hours or when tack-free
Shelf life:	12 months

## Concrete Preparation

Before coating is applied, concrete must be:

- Cured At least 28 days if new
- Dry No damp or wet areas
- Clean Contaminants removed

Brand new concrete must cure for at least 28 days prior to applying sealer. For new, untreated concrete, less preparation is required. Contaminants such as: curing agents, glue, waxes, paint, oil, dirt, water repellants, and anything that will prevent sealer adhesion must be removed. Prepare the concrete by sanding, grinding, sand blasting, shot blasting or pressure washing so that the surface will be porous enough to absorb product and bond permanently. If a pressure washer is used, use a fan tip with a minimum pressure of >2,000psi. Be careful not to leave wand patterns in the finished substrate. When applying to newly installed pavers or brick, allow grout joints to dry completely before application. On surfaces expected to have vehicle traffic, it is best to remove previously applied sealers or coatings to base concrete.

# **Patching**

The characteristics of sealed concrete allow for the user to repair cracks and imperfections only if desired. If repair is required, we recommend the use of cementitious, low-shrinking crack and spall filler. Patching must be completed at least 24 hours prior to installation of sealer.

# Testing

All surfaces are not the same. It is recommended that a sample area be done before the start of the project. The test should be done onsite, using the proposed method by the assigned applicator to ensure proper adhesion and color. A sample area should also be done on any existing coatings to determine if any contaminants exist or if delaminating will occur. Test slab for alkalinity and efflorescence.

Revision 1/8/20



## **Mixing**

- 1. Shake unopened container before use.
- One-gallon to five-gallon acetone resistant pump sprayers are recommended for application of UPC SA24 Matte.

# **Application Instructions**

After all concrete preparation has been completed and product has been thoroughly mixed, UPC SA24 Matte can be applied. UPC recommends using an acetone-rated sprayer, but a 3/4" nap, shedresistant phenolic-core roller and paint brush can also be used.

- Be sure to carefully mask surrounding areas to avoid accidental overspray. Optimum ambient temperature should be between 55-85°F.
- Tape off work areas to protect from foot traffic during application and drying. Mix up to 5 gallons of coating using above mixing instructions.
- 3. Wear protective gear. Read all safety precautions. Always use in a well-ventilated area away from sources of ignition.
- 4. Product cures quickly, so be sure to apply accordingly.
- 5. **Using an acetone-rated sprayer:** Begin spraying sealer in a circular pattern while walking from left to right, then back, right to left. Work in small, manageable sections. Try working from control joint to control joint if possible. Do not allow sealer to puddle, but keep a wet edge. Note: Avoid stepping in sealer. Spiked shoes may be worn to prevent footprints. Avoid dripping sealer on concrete. Keep a drip rag on hand.
- Using a roller and brush: First cut in around edges with brush. Then roll product on floor quickly and evenly in a "V" pattern in both directions. Roll product as thin as possible.
- Once the first coat is tack-free, a second coat can be applied evenly over the floor. Heavy traffic areas may require a third coat of sealer.
- Allow sealer to dry on the surface for at least 4-6 hours before opening area to foot traffic.

# Clean-up

UPC SA24 Matte may be cleaned with solvent. Cured material may require some scrubbing. Always clean sprayer after each use, per manufacturer's recommendations. Disposal of material must comply with all local, state and federal regulations.

### Maintenance

Maintain sealed floors by sweeping. When spills occur, clean immediately and rinse dirt from the floor with water. A wet-clean is recommended for heavily-soiled areas, using a damp mop and biodegradable cleaner or rotary floor machine equipped with a white or red buffing pad and mild commercial detergent. Repeat process until water rinses clean.

Interior sealed concrete floors can be maintained by using wax or acrylic floor finishes. If any of these products are used, please refer to manufacturer's recommended method.

### **Product Limitations**

Ground level concrete slabs emit invisible moisture vapor. The allowable moisture emissions for concrete are 3 lbs. / 1,000 SF over a 24-hour period based on a Calcium Chloride test. Also, a Relative Humidity (RH) test can be performed to test for moisture vapor. RH testing results should be below 85% per ASTM F2170. If moisture is above this level, then blistering and de-lamination of coating may occur. A calcium chloride or Relative Humidity test should be performed to determine concrete moisture levels. If moisture levels exceed the 85% for RH test or 3 lbs. for Calcium Chloride, then a concrete moisture vapor control system should be used first before applying coating system. Recommended system for cases of moisture above acceptable levels is UPC 5200. UPC 5200 Moisture Lock passes F3010 spec based on E96 testing results. Please contact UPC representative for additional details.

UPC SA24 must be used on concrete that is not susceptible to hydrostatic pressure. The concrete must be placed on a well-drained subgrade. Alkali or hard-water deposits may form on the sealer at edges, cracks, joints, or other areas where water is able to enter the concrete substrate. These deposits can also form underneath the sealer at these areas. Sealer must be applied in thin coats to prevent whitening, peeling, or becoming too slippery in areas where standing water may occur. Damp objects placed on the sealer for long periods of time may leave deposits or cause stains and discoloration in the sealer.

- · Always test a small area
- Add Non-slip where necessary (120-grit white Oxide)
- · Do not install on damp surface or if rain is expected
- If rain has occurred within 48 hours or is expected in the next 48 hours, do not apply product
- Be sure to shut off sprinklers
- Install between 55-85°F
- Do not fan or force-dry
- Coverage rates may vary

# Warranty

Universal Polymer Coatings products are warranted for one year after date of purchase. Please refer to the UPC Limited Material warranty for additional clarification.

## Safety

Consult UPC SA24 Matte Safety Data Sheet. Product contains solvent and is flammable. Remember to shut off sources of ignition before beginning work. Floor can be slippery when wet, and spiked shoes are recommended during application. Use safety goggles, rubber gloves and protective clothing when using this product. Perform work in a well-ventilated area, and use an OSHA/ NIOSH approved respirator if necessary. Protective gloves and clothing are recommended.